

Item	Frequency	Whichever Comes First		ODO meter Reading									
		*1000km	1	5	10	15	20	25	30				
		*1000mi Month	0.6	.3	6	9	12	15	18				
*	Air Cleaner		1	6	12	18	24	30	36				
	Spark Plugs			R	R	R	R	R	R				
	Throttle Operation			I	R	I	R	I	R				
*	Throttle Operation			I	I	I	I	I	I				
*	Valve Clearance			I	I	I	I	I	I				
*	Fuel Line				I		I		I				
	Crankcase Breather		C	C	C	C	C	C	C				
*	Engine Oil		R	R	R	R	R	R	R				
*	Engine Oil Screen			C	C	C	C	C	C				
*	Engine Oil Filter		R	R	R	R	R	R	R				
*	Engine Idle Speed				I		I		I				
*	Transmission Oil		R	R	R	R	R	R	R				
*	Drive Belt			I	I	I	R	I	I				

Item	Frequency	Whichever Comes First	
		*1000km	*1000mi
		Month	Month
**	Clutch Shoe Wear		
	Brake Fluid		
	Brake Pad Wear		
	Brake System		
*	Brake Light Switch		
**	Steering Bearings		
*	Headlight Aim		
*	Nuts, Bolts, Fasteners		
**	Wheels, Tyres		
**	Coolant		
**	Injector		
	Engine Rubber Cushions		